



BRAND-FIRST

BEST PRACTICES WHEN USING A TEMPERATURE REGULATOR

[1] Plug the branding tool into the temperature regulator and then plug the regulator into the wall.

[2] Dial the regulator to about 50% and let the tool heat up for about 15-20 minutes.

[3] Test brand your material at a few different dwell times (1 second, 3 seconds, 5 seconds, etc). If you are branding multiple different types of wood/leather/plastic do this on all the different pieces.

[4] If this does not give you the results you are looking for dial the regulator up 5%-10% and let the tool heat up for about 10-15 minutes.

[5] Repeats steps 3 & 4 until you get acceptable brands on all your material.

[NOTE] When branding wood, sanding the material after it's branded with a high grit paper will also help remove some overburn. You may find it helpful to make notations directly on the material stating the percentage & dwell time used and save these pieces for further reference.

www.Brand-First.com

32309 Milton Ave.

Madison Heights, MI 48071

(248)583-5353

sales@brand-first.com